

DATE 7-9-59
SH. 1 OF 2
COMPILED BY

TMC SPECIFICATION NO. S 440

TITLE: MODIFICATION KIT FOR TU/ATS-1

JOB

APPROVED A

LIST OF MATERIALS FOR TU/ATS-1 MODIFICATION KIT:

- One PM-272
- One MS-202-4-4.5
- One MS-202-1-3.75
- One PX-370-4-7 Three inches
- One TE-141-2

STEPS FOR COMPLETING MODIFICATION:

1. Remove Tuner from case as described in Section 4-2 of Instruction Book.
2. Unsolder lead from C202 to L201, cut this lead where it connects to C202.
3. Loosen nut and lockwasher from rear plate of C202 on the same side as the lead that was removed.
4. Put new 4-1/2" lead on capacitor and replace lockwasher and nut.
5. Solder other end of lead to L201 using coil lug PM-272
6. Loosen one screw of the contact spring that is mounted on the front teflon plate of the coil.
7. Crimp and solder the 3-3/4" lead to the terminal lug TE-141-2 and place under the screw on the teflon plate.
8. Place the teflon sleeving over this lead.
9. Solder the lead to the lug from which the original lead was removed.
10. Interchange the leads on the outside terminals of R203.
11. Interchange the leads on C & E of J201.
12. The modification is now complete

DATE 7-9-59
SH. 2 OF 2
COMPILED BY


TMC SPECIFICATION NO. S 440

TITLE: MODIFICATION KIT FOR TU/ATS-1


JOB

APPROVED


PRESENTLY WIRED



CHANGE TO



TO
ANTENNA
J202



TO
ANTENNA
J202

