

MATERIAL LIST

REV

MODEL TER-3500-650

SHEET 1 OF 1

QUAN. PER UNIT	PART NO.	DWG. REV.	DWG. SIZE	DESCRIPTION	REF.	LOCATION		SYMBOLS
						USED ON	QUAN.	
				<p>NOTE: USE THE TER-3500-600 MATERIAL LIST, EXCEPT IN THIS CASE, THE CORRECT COMBINATION OF RESISTORS MUST BE USED TO ARRIVE AT 650 ohms INSTEAD OF 600 ohms.</p> <hr/>				