

REQ ITEM	PART NUMBER	BREAKOUT		DESTINATION OR DESCRIPTION	
		FROM	TO	FROM	TO
1	LWC26(7)U7	6-9	5-9	XA14 PIN 9	XA15 PIN 9
2		5-9	4-9	XA15 PIN 9	XA16 PIN 9
3		4-9	3-9	XA16 PIN 9	XA17 PIN 9
4		3-9	2-9	XA17 PIN 9	XA18 PIN 9
5		2-9	7-A	XA18 PIN 9	J2 PIN E
6		6-7	5-7	XA14 PIN 8	XA15 PIN 8
7		5-7	4-7	XA15 PIN 8	XA16 PIN 8
8		4-7	3-7	XA16 PIN 8	XA17 PIN 8
9		3-7	2-7	XA17 PIN 8	XA18 PIN 8
10		2-7	7-A	XA18 PIN 8	J2 PIN F
11		6-7	5-7	XA14 PIN 7	XA15 PIN 7
12		5-7	4-7	XA15 PIN 7	XA16 PIN 7
13		4-7	3-7	XA16 PIN 7	XA17 PIN 7
14		3-7	2-7	XA17 PIN 7	XA18 PIN 7
15		2-7	7-A	XA18 PIN 7	J2 PIN G
16		6-5	5-5	XA14 PIN 6	XA15 PIN 6
17		5-5	4-5	XA15 PIN 6	XA16 PIN 6
18		4-5	3-5	XA16 PIN 6	XA17 PIN 6
19		3-5	2-5	XA17 PIN 6	XA18 PIN 6
20		2-5	1-5	XA18 PIN 6	XA19 PIN 6
21		1-5	7-A	XA19 PIN 6	J2 PIN H
22		6-5	5-5	XA14 PIN 5	XA15 PIN 5
23		5-5	4-5	XA15 PIN 5	XA16 PIN 5
24		4-5	3-5	XA16 PIN 5	XA17 PIN 5
25		3-5	2-5	XA17 PIN 5	XA18 PIN 5
26		2-5	1-5	XA18 PIN 5	XA19 PIN 5
27		1-5	7-A	XA19 PIN 5	J2 PIN J
28		6-3	5-3	XA14 PIN 4	XA15 PIN 4
29		5-3	4-3	XA15 PIN 4	XA16 PIN 4
30		4-3	3-3	XA16 PIN 4	XA17 PIN 4
31		3-3	2-3	XA17 PIN 4	XA18 PIN 4
32		2-3	1-3	XA18 PIN 4	XA19 PIN 4
33		1-3	7-B	XA19 PIN 4	J2 PIN S
34		6-3	5-3	XA14 PIN 3	XA15 PIN 3
35		5-3	4-3	XA15 PIN 3	XA16 PIN 3
36		4-3	3-3	XA16 PIN 3	XA17 PIN 3
37		3-3	2-3	XA17 PIN 3	XA18 PIN 3
38		2-3	1-3	XA18 PIN 3	XA19 PIN 3
39	LWC26(7)U1	1-3	7-B	XA19 PIN 3	J2 PIN T