

CA

CABLE INTERCONNECT CONSOLE

SHEET 1 OF 3

EQ ITEM	PART NUMBER	BREAKOUT		DESTINATION OR DESCRIPTION		TO
		FROM	TO	FROM		
1	MWC22(7)U1	6	6	TB101-1		K101-1
2	U1	6	2	K101-1		S101-IND
3	U1	7	7	TB102-1		K102-1
4	U1	7	2	K102-1		S102-IND
5	U1	8	8	TB103-1		K103-1
6	U1	8	2	K103-1		S103-IND
7	U2	6	6	TB101-2		K101-4
8	U2	6	2	K101-4		DS101
9	U2	2	2	DS101		S101 IND (w/ jumper to row B)
10	U2	7	7	TB102-2		K102-4
11	U2	7	2	K102-4		DS102
12	U2	2	2	DS102		S102 IND (w/ jumper to row B)
13	U2	8	8	TB103-2		K103-4
14	U2	8	2	K103-4		DS103
15	U2	2	2	DS103		S103 IND (w/ jumper to row B)
16	U3	6	2	TB101-3		S101A-ON
17	U3	7	2	TB102-3		S102 A-ON
18	U3	8	2	TB103-3		S103A-ON
19	U4	6	2	TB101-4		S101B-OFF
20	U4	7	2	TB102-4		S102B-OFF
21	U4	8	2	TB103-4		S103B-OFF
22	U5	6	2	TB101-5		S101B-ON
23	U5	7	2	TB102-5		S102B-ON
24	U5	8	2	TB103-5		S103B-ON
25	U6	6	4	TB101-7		J114-C
26	U7	7	4	TB102-7		J114-F
27	U8	8	4	TB103-7		J114-J
28	U9	6	4	TB101-6		J114-D
29	U91	7	4	TB102-6		J114-G
30	U92	8	4	TB103-6		J114-K
31	U0	6	6	TB101-8		GND
32	U0	6	4	GND		J114-E
33	U90	7	7	TB102-8		GND
34	U90	7	4	GND		J114-H
35	U91	8	8	TB103-8		GND
36	U91	8	4	GND		J114-L
37	U92	6	2	TB101-9		S101A-OFF
38	U93	6	2	TB101-10		SPARE