

TMC PART NUMBER CROSS REFERENCE LIST
FOR TRANSFORMERS, COILS, INDUCTORS, REACTORS

<u>NEW</u>		<u>OLD</u>
A-242	Coil	AEM096
A-243	Coil	AEM082
A-244	Coil	AEM095
A-245	Coil	AEM097
A-246	Coil	AEM098
A-247	Coil	AEM100
A-249	Coil	AEM101
A-250	Coil	AEM079
A-338	Transformer, T1	AEM007
A-339	Transformer, T2	AEM008
A-340	Transformer, T3	AEM009
A-341	Transformer, T4	AEM010
A-342	Transformer, T5, Main	AEM011
A-343	Transformer, T5, Tuning	AEM012
A-344	Transformer, T6, Main	AEM013
A-345	Transformer, T6, Tuning	AEM014
A-359	Transformer,	AEW006
A-360	Transformer, 100 KC	AEM015
A-361	Transformer, 100KC	AEM016
A-363	Transformer, FT-001	AEM018
A-364	Transformer, FT-002	AEM019
A-365	Transformer, FT-003	AEM034
TF-101	Transformer, Power	AEM035
TF-105	Transformer, Power	EM5014
		AEM031
TF-109	Transformer, Audio	MB379
TF-111	Transformer, Filament	AEM064
TF-115	Transformer, Audio	AEM033
TF-117	Transformer, Audio	MB989
TF-118	Transformer, Audio	MB988
TF-119	Transformer, Audio	MEL302
TF-5001	Inductor	AEM030
TF-5003	Reactor	MB383
TF-5006	Reactor	MB981
TR-001	Transformer	AEW001-A
TR-003	Transformer	AEM067
TR-005	Transformer	AEM065
TR-007	Transformer	AEW004
TR-011	Transformer	AEM087
		AEM086
TR-012	Transformer	AEM104
TR-013	Transformer	AEW019
TR-018	Transformer	AEM105

TMC PART NUMBER CROSS REFERENCE LIST
FOR TRANSFORMERS, COILS, INDUCTORS, REACTORS

<u>OLD</u>		<u>NEW</u>
AEM007	Transformer, T1	A-338
AEM008	Transformer, T2	A-339
AEM009	Transformer, T3	A-340
AEM010	Transformer, T4	A-341
AEM011	Transformer, T5, Main	A-342
AEM012	Transformer, T5, Tuning	A-343
AEM013	Transformer, T6, Main	A-344
AEM014	Transformer, T6, Tuning	A-345
AEM015	Transformer, 100KC	A-360
AEM016	Transformer, 100KC	A-361
AEM018	Transformer, FT001	A-363
AEM019	Transformer, FT002	A-364
AEM030	Inductor	TF-5001
AEM031	Transformer, Power	TF-105
AEM033	Transformer, Audio	TF-115
AEM034	Transformer, FT003	A-365
AEM035	Transformer, Power	TF-101
AEM064	Transformer, Filament	TF-111
AEM065	Transformer	TR-005
AEM067	Transformer	TR-003
AEM079	Coil	A-250
AEM082	Coil	A-243
AEM086	Transformer	TR-011
AEM087	Transformer	TR-011
AEM095	Coil	A-244
AEM096	Coil	A-242
AEM097	Coil	A-245
AEM098	Coil	A-246
AEM100	Coil	A-247
AEM101	Coil	A-249
AEM104	Transformer	TR-012
AEM105	Transformer	TR-018
AEW001	Transformer	TR-001
AEW004	Transformer	TR-007
AEW006	Transformer	A-359
AEW019	Transformer	TR-013
BMS014	Transformer, Power	TF-105
MB379	Transformer, Audio	TF-109
MB383	Reactor	TF-5003
MB981	Reactor	TF-5006
MB988	Transformer, Audio	TF-118
MB989	Transformer, Audio	TF-117
MEL302	Transformer, Audio	TF-119

