

DATE Sept. 11/63

SH. 1 OF 2

COMPILED BY  
LC/hh *el*

TMC

SPECIFICATION NO. S - 10085

TITLE:

JOB

APPROVED *Key*

INSTRUCTIONS FOR INSTALLATION OF

CAN-2 MODIFICATION

ON

GPR-90 RXD RECEIVER

T. M. C. (CANADA) LIMITED

OTTAWA

ONTARIO

DATE <u>Sept. 11/63</u>	TMC SPECIFICATION NO. S - 10085	
SH. <u>2</u> OF <u>2</u>		
COMPILED BY <u>LC/hh</u>	TITLE: <u>Instructions for Installation of CAN-2</u>	JOB
APPROVED	<u>Modification on GPR-90 RXD Receiver</u>	

1. Mount bracket MS-10559 to the back of the chassis.

NOTE: The audio transformer mounting bracket MS-10559 has an "A" hole and a "B" hole for mounting to the back of the chassis. The "B" hole is mounted to the collar of the IF Gain Control. A hole 5/32" in diameter is drilled in the chassis to correspond with the above mentioned "A" hole.

2. Connect the respective wires to the audio transformer (Reference CK-10316).

3. Mount the audio transformer to the bracket.

4. Mount the Terminal Strip TM-100-4 to the mounting bracket.

5. Connect the respective wires to the terminal strip (Reference CK-10316).

6. Stamp the transformer just above the terminal strip to indicate each terminal lug number.